











# PartyKEG classic

Information about closures / 03-2014

## Handling instructions for closures of PartyKEG classic

<p><b>Storage:</b> Store in a dry, cool place (10 – 30 °C / 50 – 86 °F)</p> 	 
<p><b>Disinfection:</b> The closures should be disinfected with the recommended disinfectants (dip) - 0,3% proxy acetic acid Please check other disinfectants regarding compatibility and processing.</p>	 
<p><b>Closing process:</b> Insert closure straight into the filling hole Push in closure deep enough to allow the sealing contour to snap in completely below the sealing rim of the keg</p>	 
<p>Exact positioning of the stamp depends on the equipment and has to be determined individually  Concentricity from keg to closing stamp maximum 1 mm.  Recommended stamp: according to the drawing provided by the HUBER Packaging Group.</p>	  
<p>Recommended pneumatic cylinder: Ø 63mm; operating pressure min. 5,5 bar  Periodic sampling of inserted closures by removing the lid recommended.  Best closing results will be reached by following these handling instructions.</p> 